

POOL/SPA/HOT TUB HEATING WITH A SPIREC HEAT EXCHANGER

Use Your Existing Heating System To Heat Your Pool/Spa!

Boiler ou

NO ADDITIONAL MAINTENANCE

You have an existing heating boiler that's heating your house or office, why should you install an extra one just to heat your pool?

With a Spirec heat exchanger you can use your home/office boiler to heat your pool, hot tub, or spa and eliminate the cost, hassle, and installation of an additional heating system just to heat your pool, hot tub, or spa.



You're already paying for the maintenance of 1 boiler why pay for two? With a Spirec heat exchanger, your pool, hot tub, or spa becomes an extension of your existing heating system. You'll use the same type of controls and thermostats you use to heat your house or office and automatically set the controls for the exact temperature you want your pool water to be.

NO HEADACHES

The biggest job in heating a pool, hot tub, or spa's water is heating it the first time.

After your pool or spa reaches it's desired temperature, to keep the water at that temperature might only require about 20,000-40,000 BTUs an hour. So why run a costly pool heater firing at up to 400,000 BTUs an hour when a Spirec heat exchanger can accomplish the same job with your home heating

accomplish the same job with your home heating boiler firing at only 100,000 to 200,000 BTUs an hour?

Pool Out



SAVE \$

When you install a Spirec heat exchanger to heat your pool, you won't have to spend extra money on installing an additional heater with it's electrical, exhaust stack, and gas line. You can heat your pool by simply connecting your Spirec heat exchanger to your existing boiler!



PERFECT FOR YOUR APPLICATION

Whether it's a pool, spa, or hot tub a Spirec heat exchanger is the ideal match to handle your water heating needs. From spa size to full-size pool using solar to traditional boiler heat, we have the heat exchanger to handle the capacity that your application needs.



EASY TO USE AND INSTALL

Instead of paying for and installing a heating system exclusively for your pool, you can simply connect a Spirec heat exchanger to your existing home heating boiler and heat your pool. You simply control your pool temperature through a standard thermostat.

SPIREC NORTH AMERICA

Boiler in

Web: http://www.spirec.com Email: info@spirec.com Toll Free: (800) 910-7330 Fax: (973) 569-9297